

CONTENTS

PREFACE	vii
CHAPTER 1. GENERATION OF LABORATORY SIGNALS	
1.1. Laboratory Sources of Microwave Power	1
1.2. General Characteristics of Klystrons	3
1.3. Methods of Tuning of Klystrons	9
1.4. Theory of Klystron Behavior	12
Beam Focusing—Gap Interaction—Bunching and Debunching— Large-signal Theory—Complex Bunching Systems	
1.5. The Two-cavity Klystron	20
General Remarks—Two-cavity Klystron Oscillator—The Starting Current for Two-cavity Klystron—The Operating Modes of an Oscillator—Frequency Stability and Frequency Modulation— Amplitude Modulation of Klystron Oscillator—Klystron Amplifier— Adjustment of Klystron Amplifiers—Modulation of Klystron Amplifiers	
1.6. The Reflex Klystron	33
General Description—Operating Notes—Voltage or Operating Modes—First-order Theory of the Reflex Klystron—Starting Current—Electrical Tuning—Power Output and Efficiency of a Reflex Klystron—Hysteresis—Long-line Effects—Mode Interference— Modulation of the Reflex Klystron	
1.7. Microwave Triode Oscillators	53
General Characteristics of Microwave Triode Circuits—Circuits for Microwave Triodes—Butterfly Oscillators—Coaxial-line Oscillators	
1.8. Traveling-wave Tubes	60
1.9. Backward-wave Oscillator	66
1.10. Isolation of Laboratory Oscillators	71
Attenuating Pads—Power Amplifiers—Ferrite Isolators	
1.11. Variable Transmission Modulators	76
1.12. Power Supplies for Laboratory Oscillators	81
General Requirements—Sources of Stable Voltage—Voltage-compensating Circuit for Reflex Klystrons	
1.13. Frequency Stabilization of Laboratory Oscillators	86
Stabilization of Operating Conditions—Electronic Stabilization— Cavity Stabilization	
1.14. Standard Signal Generators	90
Basic Requirements—Standard Signal Generators—Noise-signal Generators	
1.15. Crystal Rectifier Harmonic Generators	102
1.16. Sources of Radiation above the High-frequency Limit of Electron Oscillators	104

CHAPTER 2. DETECTION OF MICROWAVE POWER	108
2.1. Introduction	108
2.2. Crystal Rectifiers.	110
2.3. Crystals as Low-level Detectors Response Law—Sensitivity—Figure of Merit—Effect of D-C Bias— Dependence of Sensitivity on Temperature	113
2.4. Crystals as Converters	121
Conversion Efficiency—Noise Temperature—R-F and I-F Imped- ances—Noise Figure—Comparison of Low-level Detectors and Converters	
2.5. Crystal Types.	125
Stability and Handling of Crystals—Checking Crystal Characteris- tics	
2.6. Crystal Holders	128
2.7. Vacuum-tube Detectors.	132
2.8. Bolometers	133
Characteristics of Barretters—Comparison of Sensitivity of Crystals and Barretters	
2.9. Amplifier and Metering Circuits	137
2.10. Calibration of Detectors.	142
CHAPTER 3. MEASUREMENT OF MICROWAVE POWER	145
3.1. Introduction	145
3.2. Methods of Power Measurement	147
3.3. Validity of the Substitution Process in Barretters Skin Effect—Effect of Wire Length and Standing Waves	152
3.4. Typical Barretter Elements.	165
3.5. Thermistors	167
3.6. Resistance-film Bolometers	170
3.7. Bolometer-bridge Circuits	172
3.8. Methods of Extending the Range of Bolometric Devices	177
3.9. Measurement of Bolometer-mount Losses.	181
3.10. Measurement of Pulsed Power by Means of Bolometers	187
3.11. Microwave Calorimetry	188
Static Calorimeters—Circulating Calorimeters—Balanced Calo- rimetry—Calorimetric Loads	
3.12. Force-operated Devices	198
3.13. Miscellaneous Methods	201
CHAPTER 4. IMPEDANCE CONCEPTS AT MICROWAVE FREQUENCIES	203
4.1. Introduction	203
4.2. Transmission Lines and Wave Concepts	207
4.3. Modes of Propagation	214
4.4. Identification of Modes Waves in Rectangular Waveguides—Waves in Circular Waveguides	217
4.5. Normalized Voltage and Current; Power Flow	218
4.6. Application to Traveling Waves	219
4.7. Standing Waves in Transmission Lines	220
4.8. Some Properties of Standing Waves	223
4.9. Graphical Representation of Impedance Relations	228

	CONTENTS	xv
CHAPTER 5. MEASUREMENT OF IMPEDANCE		235
5.1. Types of Impedance Measurements		235
5.2. The Standing-wave Detector		238
Transmission Line—The Slot—The Probe		
5.3. Typical Standing-wave Detectors		249
Coaxial-line Standing-wave Detector—The Parallel-plate Coaxial Standing-wave Detector—Waveguide Standing-wave Detectors		
5.4. Signal Sources		259
5.5. Detectors and Indicators		261
5.6. Techniques in Standing-wave Detector Measurements		262
Typical Apparatus—Oscillator Adjustment—Standing-wave Detector Adjustments—Measurement of Low Standing-wave Ratios— Measurement of Medium Standing-wave Ratios—Measurement of High Standing-wave Ratios—Alternate Methods of Measuring VSWR—Location of the Voltage Minimum		
5.7. Errors in Standing-wave Detector Impedance Measurements		269
Structural Defects—Slot and Discontinuity Effects: Residual VSWR—Correction of SWD Data for Residual VSWR—Effect of Attenuation		
5.8. Precision Measurement of Small Reflections		275
The Nodal-shift Method—The Cavity Method—The Sliding-termina- tion Method		
5.9. Resonance-curve Method of Impedance Measurements (Chipman Method)		287
5.10. Bridge Methods of Impedance Measurements		293
Magic-T Bridge—Wheatstone-bridge Circuits—Pseudo-bridge Cir- cuits		
5.11. Reflectometers		300
5.12. Multiple-probe Method		303
5.13. Low-level Impedance Measurements		307
5.14. Dynamic Presentation of Impedance Data		307
CHAPTER 6. REPRESENTATION AND MEASUREMENT OF MICROWAVE CIR- CUITS		313
6.1. Introduction		313
6.2. Some Possible Methods of Representation		317
T and π Networks—Scattering-coefficient Representation—The Tangent (Transformer) Method—Canonical Networks		
6.3. Relationships between Various Representations		326
T Network and Scattering Representation—T Network and Tangent Relationship—T Circuit and Canonical Relationship		
6.4. Symmetry Considerations		329
Far-field Standing-wave Solutions		
6.5. Measurement and Analysis of Data		334
The Three-point Method—Graphical Determination of the Scatter- ing Coefficients—Canonical Networks		
CHAPTER 7. MEASUREMENT OF WAVELENGTH		346
7.1. Introduction		346
7.2. Equivalent Circuit of the Cavity Wavemeter		352
7.3. Mode Charts for Cavity Wavemeters		354

7.4. Typical Wavemeters	357
Methods of Coupling and Loading Errors—Coaxial Wavemeter— TE ₁₁₁ -mode Wavemeter—TE ₀₁₁ -mode Wavemeter	
7.5. Precision Comparison of Resonant Cavities	367
7.6. Effect of Temperature and Humidity upon Cavity Calibration	371
7.7. Application of Optical Methods	371
CHAPTER 8. MEASUREMENT OF FREQUENCY	375
8.1. Introduction	375
8.2. Standards of Frequency	378
Primary Standards of Frequency—Secondary Standards of Frequency—Molecular Spectral Lines as Frequency Standards—Cavity Resonators as Frequency Standards	
8.3. Microwave-frequency Standards	382
Standard-frequency-sequence Generator—Crystal Rectifiers as Harmonic Generators—Variable-frequency Standard	
8.4. Methods of Frequency Measurement	386
Direct Measurement—Interpolation Method—Additive-frequency Method	
8.5. Heterodyne Frequency Meter	389
CHAPTER 9. RESONANT-CAVITY CHARACTERISTICS: MEASUREMENT OF Q	391
9.1. Introduction	391
Equivalent Circuits; Definitions of Q_0 , Q_L , Q_{ext} , and Coupling Coefficient β —Q Circles—Types of Q Measurements	
9.2. Transmission Method	403
9.3. The Impedance Method	405
Interpretation of Impedance Data—The Standing-wave Ratio Method—The Phase Method	
9.4. Impedance Method—Effect of Coupling Loss	424
9.5. The Decrement Method	428
9.6. Dynamic Methods	431
CHAPTER 10. RESONANT-CAVITY CHARACTERISTICS: MEASUREMENT OF R_0/Q_0	435
10.1. Introduction	435
10.2. The Perturbation Method: Low-frequency Analogue	436
10.3. Slater Perturbation Theorem	438
10.4. Application to Cavity with Constant Electric Field	440
10.5. Application to Cavities with Variable Fields	443
10.6. Determination of Field Components in Cavity Resonators	445
Perturbation by Metallic Spheres—Perturbation by Metallic Needles —Perturbation by Metallic Disks	
10.7. Study of Periodically Loaded Structures	452
10.8. Measurement of Nonresonant Waveguide Impedance	454
10.9. Miscellaneous Methods of R_0/Q_0 Measurement	457
Resistance-variation Method—Electron Velocity-spectrograph Method—Modulation-sensitivity Method—Induced Shot-noise Method	
CHAPTER 11. MEASUREMENT OF ATTENUATION	462
11.1. Introduction	462
Definition of Attenuation—Methods of Measurement	

11.2. The Insertion or Power-ratio Method	467
11.3. Substitution Method	467
11.4. Cavity-resonance Method	469
11.5. Scattering-coefficient Method	471
APPENDIX A. FIELD CONFIGURATIONS AND CUTOFF WAVELENGTHS FOR COMMON WAVEGUIDES	477
APPENDIX B. FORMULAS AND CONSTANTS	491
B.1. Some Useful Vector Formulas	491
B.2. Some Physical Constants	491
B.3. Conversion Factors	492
B.4. Skin Depth	492
INDEX	495