
Contents

Preface	xiii
1 Introduction and fundamental concepts	1
1.1 Introduction	1
1.2 Electrical volumetric heating	2
1.2.1 Conduction and induction heating	2
1.2.2 Ohmic heating	2
1.2.3 Radio frequency heating	3
1.2.4 Microwave heating	3
1.3 The electromagnetic spectrum	5
1.4 Electromagnetic fields	7
1.4.1 Electric fields	7
1.4.2 Magnetic fields	8
1.4.3 Electromagnetic induction	10
1.4.4 Maxwell's equations	10
1.4.4.1 Boundary conditions	11
1.5 Plane waves	13
1.6 Power flow and the Poynting vector	16
2 Microwave interaction with dielectric materials	19
2.1 Introduction	19
2.2 Relative permittivity	20
2.2.1 Complex relative permittivity and dielectric loss factor	20
2.2.2 Dielectric loss angle	21
2.3 The dielectric heating equation	21
2.3.1 Internal and external electric-field stress	23
2.3.2 Tables of E_i and E_{ext} at ISM frequencies for a range of dielectric properties	24
2.4 Dielectric properties of materials	24
2.5 Penetration depth	32
2.6 Limits on power-dissipation density	35
2.6.1 Thermal limitations	35

2.6.2 Voltage breakdown and arcing	36	4.3.6 Impedance transformation in lossy transmission lines	99
2.6.3 Thermal runaway	38	4.4 Twin open-wire, coaxial and parallel-plate transmission lines	100
2.7 The engineering aspects of power-dissipation density in applicator design	39	4.4.1 Coaxial-line TEM-mode data	101
2.8 Processing at elevated pressure	41	4.5 Rectangular waveguides	104
2.8.1 Pressure locks	41	4.5.1 H or TE modes in rectangular waveguide	105
2.8.2 Microwave pressure windows	42	4.5.2 Cutoff and waveguide wavelengths	108
2.8.2.1 Pressure windows: microwave design	43	4.5.3 Field equations: the fundamental TE ₁₀ or H ₁₀ mode	109
2.8.2.2 Pressure windows: mechanical design	47	4.5.4 Characteristic impedance	110
2.8.2.3 Pressure windows: protection	48	4.5.5 Power flow, electric- and magnetic-field intensity, wall-current density	112
2.9 Processing under vacuum	48	4.5.6 Attenuation	113
2.9.1 Applicators for vacuum processing	49	4.5.6.1 Skin depth	114
2.9.2 Vacuum windows	50	4.5.7 TM or E modes in rectangular waveguide	116
3 The thermodynamic aspects of volumetric heating	53	4.6 Circular waveguides	118
3.1 Introduction	53	4.6.1 Cutoff circular-waveguide chokes	120
3.2 Power and energy	54	4.7 Waveguide practice	123
3.3 Volumetric and conventional heating: a comparison	54	4.7.1 Waveguide size	123
3.4 Batch and continuous processes	55	4.7.2 Materials and construction methods	124
3.5 Heat balance	56	4.7.3 Seams and joints in microwave equipment	125
3.5.1 Heat balance: stability	56	4.7.4 Waveguide flanges	125
3.5.2 Sensible and specific heat	57	4.7.5 Waveguide bends and twists	127
3.5.3 Heat capacity of mixtures	60	4.8 Waveguide components	129
3.5.4 Latent heat	62	4.8.1 Terminating loads, high-power	129
3.5.5 Drying techniques	63	4.8.2 Terminating loads, low-power	130
3.5.5.1 Microwave forced drying	63	4.8.3 Short-circuit terminations	130
3.5.5.2 Microwave-assisted drying	64	4.8.4 Waveguide 3-port T-junctions	131
3.5.6 Tempering and thawing	68	4.8.5 Directional couplers, 4-port	133
3.5.6.1 Heat balance in tempering and thawing	68	4.8.5.1 Directional couplers: definitions	134
3.6 Surface heat transfer	70	4.8.5.2 Directional couplers: types	136
3.6.1 Convection	71	4.8.6 4-port 'hybrid' junctions	142
3.7 Heat conduction within the workload	74	4.8.7 General properties of hybrid junctions	144
3.7.1 Heat flow in a thick slab	74	4.8.7.1 The on-load tuner	145
3.7.1.1 Heat distribution after volumetric heating	75	4.8.7.2 On-load high-power dividers and attenuators	146
3.7.1.2 Transient heat flow	76	4.9 Multiscrew tuners	148
3.7.1.3 Heat flow with surfaces maintained at fixed temperature during soaking	78	4.10 Circulators	149
3.7.1.4 Heat flow with surfaces insulated during soaking	80	5 Microwave-heating applicators I: multimode ovens	151
3.8 Power derating due to nonuniform heating	80	5.1 Introduction	151
4 Microwave transmission: theory and practice	83	5.2 Mode structure	153
4.1 Introduction	83	5.3 Mode spectrum density	154
4.2 Impedance matching	84	5.4 Mode Q-factor	156
4.2.1 Generator output impedance: optimum matching of load	84	5.5 Equivalent circuit of a multimode cavity	159
4.3 Forward and reflected waves	86	5.5.1 Microwave efficiency	162
4.3.1 Reflection and transmission coefficients, scattering coefficients	87	5.6 Heating uniformity	163
4.3.2 Standing waves and standing-wave ratio	90	5.6.1 Workload limitations	163
4.3.3 Impedance and admittance	93	5.6.2 Oven effects	165
4.3.4 Impedance transformation: the Smith chart	94	5.6.3 Feed systems	167
4.3.5 Impedance-matching procedure	98	5.6.3.1 Feed systems for continuous-flow ovens	168
		5.6.3.2 Feed systems for batch ovens	175
		5.7 Techniques for improving heating uniformity	176

5.7.1 'Mode stirrers'	177
5.7.2 Modulation of the feed system	178
5.7.3 Movement of the workload	179
5.8 Doors, chokes and open entry ports	180
5.8.1 Doors	180
5.8.2 Door chokes	181
5.8.3 Open entry ports	182
5.9 Numerical methods of analysis	187
5.10 Conveyor systems	189
5.10.1 Conveyor types and materials	190
5.10.2 Conveyor drives	191
5.10.3 Belt tensioning	191
5.10.4 Belt tracking	191
5.10.5 Belt-speed measurement	192
5.10.6 Belt and equipment maintenance	192
6 Microwave-heating applicators 2: aperiodic structures	193
6.1 Introduction	193
6.2 Axial travelling-wave structures	194
6.2.1 Longitudinal TE_{10} waveguide	194
6.2.2 Longitudinal slow-wave structures	195
6.2.2.1 Corrugated planar-surface structures (periodic arrays)	195
6.2.2.2 Helical-waveguide and corrugated-tubular-waveguide applicators	196
6.2.3 Parallel-plate transmission-line applicators	198
6.3 Transverse travelling-wave structures	200
6.3.1 Transverse waveguide, TE_{10} mode	200
6.3.2 Serpentine or meander-line applicators	202
6.3.3 Transverse E-field applicator	204
7 Microwave-heating applicators 3: resonant structures	209
7.1 Introduction	209
7.2 Input impedance and matching	210
7.3 Open-loop frequency stability	212
7.4 Tuning techniques	213
7.4.1 Applicator tuning	213
7.4.2 Generator tuning	216
7.5 Frequency discriminators	216
7.5.1 Microwave frequency discriminators	216
7.6 TM_{010} circular waveguide cavity	221
7.7 Transverse rectangular waveguide cavity, TE_{10N} mode	222
7.8 Travelling-wave applicators	223
7.9 Near-cutoff TE_{10} resonant rectangular waveguide	226
8 Choking (attenuation) tunnels for continuous-flow applicators	229
8.1 Specifications	229
8.1.1 Safety	230
8.1.2 Radio-frequency interference	230
8.2 Classification of choking methods	231
8.3 Attenuation of large, partially filled choke tunnels	232

8.3.1 Part-filled height	234
8.3.2 Part-filled width	236
8.4 Reactive (reflective) choking	238
8.5 Active electronic systems	243
8.6 Microwave fuses	244
8.7 Screened rooms	245
8.8 Choking of drive shafts	246
9 Microwave generators 1: microwave power tubes	247
9.1 Introduction to microwave power sources	247
9.2 Klystron generators	248
9.2.1 Klystrons: principle of operation	248
9.3 Magnetrons	250
9.3.1 Magnetrons: principle of operation	251
9.3.2 Magnetrons: performance characteristics	254
9.3.2.1 Electrical inputs	255
9.3.2.2 Mismatched loads: frequency and power 'pulling'	257
9.3.2.3 Frequency-pulling figure	259
9.3.2.4 Frequency-pushing figure	260
9.3.2.5 Rieke diagram	260
9.4 Stability	262
9.4.1 Transfer function with a closed loop	262
9.4.2 Moding, $(\pi - 1)$ mode, spurious emissions	264
9.4.3 Long-line effect and resonant high- Q -factor loads	266
9.4.4 Anode-current surges and arcing	268
9.5 Cooling	271
9.5.1 Liquid cooling	271
9.5.2 Air cooling	271
9.6 Operation practice	272
9.6.1 Start-up procedures	272
9.6.2 Automatic protection systems	273
9.6.3 Restart after a fault trip	274
9.6.4 Shut-down procedure	274
9.7 Magnetron life	275
9.7.1 Magnetron rebuilding	276
10 Microwave generators 2: electrical power sources	277
10.1 General requirements	277
10.2 Variable-voltage supplies	278
10.2.1 Variable transformer ratio	278
10.2.2 Thyristor-phase-angle control	279
10.2.3 Saturating-transformer control	280
10.3 Conventional power-frequency supplies for high-power magnetrons	284
10.3.1 EHT DC anode supply	285
10.3.2 Stored energy and fault energy	286
10.3.3 Power control by electromagnet	287
10.3.3.1 Separately excited electromagnet	287
10.3.3.2 Series-magnet control	291
10.3.4 Control-loop stability: effect of RF load	292
10.3.5 Cathode supplies	293

xii *Contents*

10.3.6 Electromagnet supplies	294
10.4 Switch-mode power supplies	294
10.4.1 Pulsed resonant inverter	295
10.4.2 Boucherot inverter	298
10.4.3 EHT circuits for resonant inverters	300
10.4.4 Resonating inductors and capacitors	300
10.4.5 Switching devices	301
10.5 Power supplies: a large number of low-power units, or vice versa?	301
11 Outline of microwave measurements on components and materials	305
11.1 Introduction	305
11.2 Measurements on waveguide components	306
11.2.1 Measurement of VSWR, reflection and transmission coefficients, the Smith chart	306
11.2.2 Measurement of attenuation and coupling	308
11.3 Measurements on dielectric materials	310
11.3.1 Insertion-loss measurement of dielectric properties	310
11.3.2 Resonant-cavity techniques	311
11.3.3 Surface-contact techniques	313
12 Procedures for testing high-power installations	315
12.1 Introduction	315
12.2 Microwave generators	315
12.2.1 Power input, output and efficiency	315
12.2.1.1 AC input-power measurement	316
12.2.1.2 Microwave-power-output measurement	318
12.2.1.3 Efficiency	321
13 Equipment safety	323
13.1 Review of hazards	323
13.2 Microwave leakage	323
13.3 Measurement of microwave leakage	325
13.4 High-voltage protection	326
13.5 Radio-frequency interference (RFI)	327
13.5.1 Elementary calculations of radio interference	328
Appendix 1: Outline of the economics of industrial microwave processing	331
Appendix 2: Specification of industrial microwave equipment	335
Appendix 3: Glossary of terms and symbols	339
Appendix 4: F_0 values, Z values, L_V values and D values	347
Appendix 5: Q-BASIC program for mode counting in multimode ovens	349
Appendix 6: Definitions of moisture content	351
References	353
Index	359