

Contents

1	Introduction	1
1.1	General Introduction	1
1.2	Outline and Scope	3
2	Review of Gyro-Devices	7
2.1	Introduction	7
2.2	Classification of Fast Wave Microwave Sources	8
2.2.1	Gyrotron Oscillator and Gyroklystron Amplifier	11
2.2.2	Cyclotron Autoresonance Maser (CARM)	12
2.2.3	Gyro-TWT (Travelling Wave Tube) and Gyrotwystron Amplifier	16
2.2.4	Gyro-BWO (Backward Wave Oscillator)	17
2.2.5	Overview of Gyro-Devices	18
2.2.6	Magnicons and Gyroharmonic Converters	19
2.2.7	Free Electron Lasers	20
2.3	Remarks	24
3	Basic Principles and Gyrotron Cavities	25
3.1	Basic Principle of Gyrotrons	25
3.2	Eigenmodes of Tapered, Open Resonator Cavities	31
3.2.1	Physical Model for the High Frequency Fields in a Resonator	32
3.2.2	Coaxial Cavity Structures	39
3.2.3	Complex Cavities	41
3.3	Remarks	43
4	Calculation of RF Behaviour	45
4.1	Equation of Motion	45
4.2	Self-Consistent Calculations	57
4.3	Dimensionless Variables	62
4.4	Mode Competition in Gyrotron Oscillators	67
4.4.1	Energy Transfer to a Single Mode	70
4.4.2	Mode Suppression	71
4.4.3	Startup	72
4.4.4	Time Dependent Formulation	74

4.4.5 Current Neutralization	75
4.4.6 Mode Competition with Different Harmonics	77
5 Practical Considerations for Gyrotron Design	83
5.1 Introduction	83
5.2 Wall Losses	83
5.3 Voltage Depression and Limiting Current	87
5.4 Choice of Beam Radius	90
5.5 Fresnel Parameter	91
5.6 Starting Current	91
5.7 Rieke Diagrams for Gyrotrons	98
6 Electron Optical and Guiding System	103
6.1 Introduction	103
6.2 Magnetron Injection Gun	103
6.2.1 General Remarks	103
6.2.2 Preliminary Design	106
6.2.3 Codes for the Design of MIGs	108
6.2.4 Design Procedure of MIGs	109
6.3 Beam Guidance	112
6.4 Beam Dump-Collecting System	116
6.4.1 General Remarks	116
6.4.2 Theory of Depressed Collectors	117
6.4.3 Magnetic Decompression	118
6.4.4 Design of Depressed Collectors for Gyrotrons	120
6.4.5 Some General Remarks	124
7 Output Taper and Quasi-optical Launcher	127
7.1 General Remarks	127
7.2 Output Taper	128
7.2.1 Methods of Taper Analysis and Synthesis	129
7.3 Quasi-optical Mode Converter	133
7.3.1 Basic Principle of Quasi-optical Mode Converters	135
7.3.2 Improved Quasi-optical Mode Converters	137
7.4 Concluding Remarks	145
8 RF Window	147
8.1 General Remarks	147
8.2 Practical Aspects of High Power Windows	148
8.3 Theory of Disc Type Windows	152
8.4 Broadband Output Windows	155
8.5 Diamond Windows for Gyrotrons	157
8.6 Concluding Remarks	160
9 Examples	163
9.1 General Remarks	163
9.2 A Very High-Power, 140 GHz Conventional Gyrotron	164
9.3 A 165 GHz Coaxial Gyrotron	169
9.4 Multifrequency Gyrotron	172
9.5 Second Harmonic Gyrotrons	176
9.6 Concluding Remarks	181
10 Applications	183
10.1 Introduction	183
10.2 ECRH Applications	185
10.3 ECR Discharges for Generation of Multiply Charged Ions and Soft X-Rays	186
10.4 High Frequency Broadband ESR Spectroscopy	188
10.5 Processing of Advanced Ceramics	190
10.5.1 Experimental Setup	192
10.5.2 Experimental Results	194
10.6 Millimeter-Wavelength Radar	199
10.6.1 Active Millimeter Wave Meteorology-Cloud Radar	200
10.6.2 Space Debris Monitoring Radar	202
10.6.3 High Power Nanosecond Radar	202
10.7 RF-Drivers for TeV Linear Colliders	204
References	207
Index	225